

# **When I turn my Otech computer on I get a blank screen with a number counting upwards in the top left corner. What does this mean?**

The system is checking to see how much memory is available. This can occur if there was a recent hardware change or if the CMOS battery needs to be replaced. The number will count upwards to the total amount of RAM (i.e. 1024 MB), or you can press ESC to end it quickly.

---

Article ID: 202

Last updated: 30 Nov, 2012

Revision: 1

Information Technology Services -> Otech -> When I turn my Otech computer on I get a blank screen with a number counting upwards in the top left corner. What does this mean?

<https://www2.owens.edu/faq/entry/202/>